

WINNERS ONLY® ASSEMBLY INSTRUCTIONS

PROD. NO : AA400SR / AA400SP

Thank you for purchasing this quality product. Please read the instructions thoroughly before unpacking the assembly parts.

Caution: sharp exposed staple tips can cause injury, therefore for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.

1. We recommend that you should assemble this product with the assistance of another person; this will make the assembly easier, and will help to prevent personal injury and to insure parts are not damaged during the assembly process.




2. Before beginning, please check the packing materials carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.

3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surfaces and also check for staples or nails left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.

4. Please do not over tighten screws or bolts. During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.

5. Please lay all parts and hardware on a non abrasive surface such as a carpet, and follow the assembly

Hardware List :

COMPONENTS LIST				QTY	NO	DESCRIPTION	SIZE	FIGURE	QTY
A	Table Top		1pc	1	Long Bolt	Ø5/16"x 64mm		12pcs	
B	Table Legs		4pcs	2	Spring Washer	Ø5/16"x 12mm		12pcs	
				3	Flat Washer	Ø5/16"x 19mm		12pcs	
C	Bottom Shelf		1pc	4	Allen Key	58x 23x 4mm		1pc	

IMPORTANT NOTE:

- Please keep all hardware parts out of the reach of children.
- Two or more people are needed for assembly.


TIP: store the Allen key and or Wrench used in assembly in this product's drawer or use masking or painter's tape to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS


STEP 1:

Place Table Top (A) flat down on a soft surface such as a carpet. Use long bolt (1), spring washer (2), flat washer (3) to attach three Legs (B), to Table Top (A) as shown in the diagram. Tighten with allen key (4).




STEP 2:

Use long bolt (1), spring washer (2), flat washer (3) to attach the Bottom Shelf (C) to Legs (B). Tighten with allen key (4).



STEP 3:

Attach the last Leg (B) to the Table Top (A), by using long bolt (1), spring washer (2), flat washer (3). Attach the last Leg (B) to Bottom Shelf (C) by using long bolt (1), spring washer (2), flat washer (3). Tighten with allen key (4).



STEP 4:

Please assemble the drawer handle as shown. Assembly is now complete. Thank you for your purchase.

