

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS

PROD. NO: AU300CW / AU300CN

Thank you for purchasing this quality product. Please read the instructions thoroughly before unpacking the assembly parts.




Caution : Sharp exposed staple tips can cause injury, therefore for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.



1. We recommend that you should assemble this product with assistance of another person; this will make the assembly easier, and will help to prevent personal injury and to insure parts are not damaged during the assembly process.
2. Before beginning, please check the packing materials carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.
3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surfaces and also check for staples or nails left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.
4. Please do not over tighten screws or bolts. During normal use everyday, screws, bolts, nuts, and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.
5. Please lay all parts and hardware on a non abrasive surface such as carpet, and follow the assembly.

This product will take 25-30 minutes to assemble

Components List: AU300CW / AU300CN

NO	DESCRIPTION	SKETCH	QTY
A	TABLE TOP		1 PC
B	TABLE LEG (R)		2 PCS
C	TABLE LEG (L)		2 PCS
D	LEG SUPPORT		2 PCS

Hardware List:


NO	DESCRIPTION	SIZE	SKETCH	QTY
1	JCBC BOLT WITH WASHER	M6 X 60mm		8 PCS
2	JCBC BOLT WITH WASHER	M6 X 30mm		4 PCS
3	JCBC BOLT WITH WASHER	M6 X 35mm		2 PCS
4	ALLEN KEY (BALL SHAPE)	M4		1 PC

TIP: store the Allen key and or Wrench used in assembly in this product's drawer or use masking or painter's tape to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.

WINNERS ONLY®

ASSEMBLY INSTRUCTIONS


PROD. NO: AU300CW / AU300CN



Step 1.1 Cross over Table Leg Left (B) to Table Leg Right (C) as shown on FIG 1.1.

Step 1.2 Turn Table Top (A) upside down on a soft protective surface such as carpet. Attach Table Leg Left (B) and Table Leg Right (C) to Table Top (A) using JCBC Bolt with washer (1) and Allen Key (4) as shown on FIG 1.2.


Note : Please do not fully tighten the bolts.



Step 2.1 Repeat Step 1.1 for the next Table Leg Left (B) & Table Leg Right (C) as shown on FIG 2.1.


Step 2.2 Tighten it by using JCBC Bolt with washer (1) and Allen Key (4) as shown on FIG 2.2.

Note : Please do not fully tighten the bolts.



Step 3 Align both Leg Support (D) into the designated hole at both of the Table Leg Left & Right (B & C) by using JCBC Bolt with washer (2) and Allen Key (4) as shown on FIG 3.

Note : Please do not fully tighten all the bolts now.



Step 4 Tighten both Leg Support (D) to Table Top (A) by using JCBC Bolt with washer (3) and Allen Key (4) into the wooden block of Leg Support (D) as shown on FIG 4.

Note : Please fully tighten all the bolts now.

Assembly is now complete.

2 OF 2