


# WINNERS ONLY® Assembly Instructions

DC33660R / DC33660G

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

## COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
DC33660R-01/ DC33660G-01		Hardware Bag	1 pce
DC33660R-13/ DC33660G-13		Table Top	1 pce
DC33660R-07/ DC33660G-07		Legs	4 pcs

## HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Hex Bolt	8 pcs
2		Lock Washer	8 pcs
3		Flat Washer	8 pcs
4		Wrench	1 pce


This product will take 15-20 minutes to assemble.

### Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

### NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.




# WINNERS ONLY® Assembly Instructions

DC33660R / DC33660G

## ASSEMBLY :


### STEP 1

1. Turn table top upside down on a soft protective surface such as a carpet. Insert table legs into table top using the provided hardware as shown on Fig1.



### STEP 2

- 2.1- Turn table to upright position.
- 2.2- Once table is fully balance fully tighten all bolts.



Assembly is now Completed.

#### CARE INSTRUCTION

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.