

# WINNERS ONLY® Assembly Instructions

## DC3470BR / DC3470BG

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

### COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
DC3470BR-01 / DC3470BG-01		Hardware Bag	1 pce
DC3470BR-16 / DC3470BG-16		Table Top	1 pce
DC3470BR-04 / DC3470BG-04		Drawer	3 pcs
DC3470BR-06 / DC3470BG-06		Door Glass	2 pcs
DC3470BR-07 / DC3470BG-07		Glass Shelf	4 pcs
DC3470BR-20 / DC3470BG-20		Handle	5 pcs
DC3470BR-30 / DC3470BG-30		Plastic Nail	2 pce
DC3470BR-22 / DC3470BG-22		Levelers	3 pcs
DC3470BR-29 / DC3470BG-29		Center Bun Foot	1 pce

### HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Shelf Pin Supporter	16 pcs

This product will take 15-20 minutes to assemble.

#### Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

#### NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.

