

# WINNERS ONLY®

## ASSEMBLY INSTRUCTIONS

PROD. NO : DFMT145024 / DFDT45124N

Thank you for purchasing this quality product. Please read the instructions thoroughly before unpacking the assembly parts.

Caution: sharp exposed staple tips can cause injury, therefore for your protection, please remove any exposed staples used in packing.

Please keep all hardware parts out of the reach of children.

1. We recommend that you should assemble this product with the assistance of another person; this will make the assembly easier, and will help to prevent personal injury and to insure parts are not damaged during the assembly process.

2. Before beginning, please check the packing materials carefully for small parts which may have come loose inside the carton during shipping. Please do not discard any packing material until all parts have been located. If any parts are missing, please contact your dealer for prompt replacement.




3. To prevent damage to your floor or carpet, please check the bottom of each piece of furniture for stain residues and rough surfaces and also check for staples or nails left after removing the packing materials. The manufacturer will not be held responsible if preventive steps are not taken prior to installation.

4. Please do not over tighten screws or bolts. During normal use everyday, screws, bolts, nuts and wooden plugs may loosen up. They should be periodically inspected and re-tightened to prevent damage to the furniture and (or) personal property or cause injury. Always check to be sure all hardware on this list and the below mentioned components are attached to the furniture properly and kept tightened.



5. Please lay all parts and hardware on a non abrasive surface such as a carpet, and follow the assembly

This product will take 15-20 minutes to assemble

### Components List :

| NO | DESCRIPTION            | SKETCH  | QTY |
|----|------------------------|---|-----|
| A  | Back Frame             |  | 1pc |
| B  | Cushion Seat           |  | 1pc |
| C  | Seat Frame             |  | 1pc |
| D  | Front Leg (Left)       |  | 1pc |
| E  | Front Leg (Right)      |  | 1pc |
| F  | Side Stretcher (Left)  |  | 1pc |
| G  | Side Stretcher (Right) |  | 1pc |
| H  | Front Stretcher        |  | 1pc |

### Hardware List :

| NO | DESCRIPTION   | SIZE        | SKETCH  | QTY   |
|----|---------------|-------------|---|-------|
| 1  | Wrench        | 12x75 mm    |  | 1pc   |
| 2  | Allen Key     | 58x23x4 mm  |  | 1pc   |
| 3  | Short Bolt    | 1/4" x38 mm |  | 3pcs  |
| 4  | Long Bolt     | 1/4" x85 mm |  | 4pcs  |
| 5  | Hex-Nut       | 5/16"       |  | 4pcs  |
| 6  | Spring Washer | 5/16" x Ø12 |  | 11pcs |
| 7  | Flat Washer   | 5/16" x Ø19 |  | 11pcs |
| 8  | Wood Screw    | Ø8 x 45 mm  |  | 6pcs  |

TIP: store the Allen key and or Wrench used in assembly in this product's drawer or use masking or painter's tape to affix it to the underside of the product. This will make it easier to find if you want to periodically tighten bolts or disassemble the product.

#### Reminders

1. Use only the hardware supplied.
2. Once the chair is finished, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening.

#### NOTE :

1. Hardware pack is located underneath the Cushion Seat (B).
2. Two or more people are needed for assembly. Please keep all hardware parts out of the reach of children.


# WINNERS ONLY®

## ASSEMBLY INSTRUCTIONS

PROD. NO : DFMT145024 / DFDT45124N


Grab hardware bag from underneath the Cushion Seat.  
Do not fully tighten bolts until the Product is level  
and the assembly of the product is completed.

### STEP 1




Step1: Attach the Seat Frame (C) with Cushion Seat (B) to Back Frame (A) by using Flat Washer (7), Spring Washer (6) and Bolt (3&4).

### STEP 2



Step2: Attach Side Stretcher (F&G) to Back Frame (A) using Wood Screws (8) through pre-drilled holes of Side Stretcher (F&G) and Back Frame (A). Assemble Front Stretcher (H) to Front Legs (D&E) using Wood Screw (8). Attach the assembled Front Leg (D&E) and Front Stretcher (H) to Seat Frame (C) by using Flat Washers(7), Spring Washers (6) and Hex-Nut (5). Attach Front Legs (D&E) to the Side Stretcher (F&G) using Wood Screws (8) through pre-drilled holes on the Side Stretcher (F&G).



Assembly is now complete  
Thank you for choosing this product.