




# WINNERS ONLY®

## Assembly Instructions

DPRT12024 / DRT245024

Thank you for purchasing this quality product. Be sure to check all packaging material carefully for small parts that may have come loose inside the carton during shipment.

### COMPONENT LIST:

PART NO	FIGURE	DESCRIPTION	QTY
DPRT12024-01 DRT245024-01		Hardware Bag	1 pce
DPRT12024-02 DRT245024-02		Chair Back	1 pce
DPRT12024-03 DRT245024-03		Wood Seat	1 pce
DPRT12024-06 DRT245024-06		Front Leg (Left)	1 pce
DPRT12024-05 DRT245024-05		Front Leg (Right)	1 pce
DPRT12024-10 DRT245024-10		Front Stretcher	1 pce
DPRT12024-07 DRT245024-07		Side Stretcher (L/R)	2 pcs

### HARDWARE LIST:

PART NO	FIGURE	DESCRIPTION	QTY
1		Pan Head Screw	6 pcs
2		JCBC Bolt (Short)	2 pcs
3		JCBC Bolt (Long)	6 pcs
4		Lock Washer	8 pcs
5		Flat Washer	8 pcs
6		Allen Key	1 pce
7		Glue	1 pce


This product will take 15-20 minutes to assemble.

#### Reminders

1. Use only the hardware supplied.
2. Once the product is assembled, level and tighten all the bolts.
3. Do not over-tighten bolts.
4. This item may require periodic tightening

#### NOTE:

1. Two or two people are needed for assembly
2. Please keep all hardware parts out of the reach of children.



# WINNERS ONLY®


## Assembly Instructions

DPRT12024 / DRT245024


### ASSEMBLY :

#### STEP 1

Step1: Attached wood seat to the chair back using the provided hardware as shwon on Fig.1.1 and Fig.1.2.  
 Step2: Attached front legs (Left and Right) to wood seat and the side and front stretchers to front legs and chair back using the provided hardware as shown in Fig.2.1 and Fig.2.2




#### STEP 2



#### STEP 3

- 3.1- Turn the chair to standing position.
- 3.2- Check it's balance and tighten all screw and bolts to complete the assembly.



Assembly is now Completed.

**CARE INSTRUCTION**

- ~ Be sure to use the same type of polish consistently. Your furniture will appear cloudy or streaky if oil based or wax based polishes are interchanged.
- ~ Spray your furniture surface evenly. Wipe in a circular motion with a soft clean cloth.